

Programming Improvements

Milestone 1: Turning Algorithm

Precise Short Bursts:

- Replaced one single sweep with multiple small bursts.
- Every burst has a high PWM value to overcome grooves in the tiles.
- Color sensor reading between each burst allows precise recognition.

```
void correctLeftBoundary() {  
    float r, g, b, lux;  
    for (int i = 0; i < 10; i++) {  
        // a few quick nudges  
        delay(50);  
        pivotRight(150, 150);  
        delay(200);  
        motorsBrake();  
        delay(10);  
  
        String c = readColorOnce(r, g, b, lux);  
  
        // Still on BOUNDARY? Keep nudging.  
        if (c == LEFT_BOUNDARY_COLOR) continue;  
  
        // We've left WHITE: could now be BLACK/BLUE/YELLOW or something else.  
        // Mark that we just came off a boundary so the next forward step is gentle.  
        justRecoveredFromBoundary = true;  
        return;  
    }  
    motorsBrake();  
}
```

Turning algorithm

Milestone 2: Lux Readings

Computing lux values:

- Problem: Black tape and the Floor had similar RGB readings.
- Solution: Added code to color sensing section to calculate lux values.
- Enabled differentiation between the floor and the black tape, allowing backtracks when the rover crosses margin tapes.

```
inline String readColorOnce(float &r, float &g, float &b, float &lux) {  
    ...  
    ...  
    // Optional: also compute lux from raw data  
    uint16_t c, ri, gi, bi;  
    tcs.getRawData(&ri, &gi, &bi, &c);  
    lux = tcs.calculateLux(ri, gi, bi);  
    return detectColor(r, g, b, lux);  
}
```

Lux computation

```
// ----- FLOOR FALL PROTECTION -----  
if (color == "FLOOR") {  
    motorsBrake(); delay(100);  
    motorsBackward(50, 50); delay(10);  
    return true;  
}
```

"FLOOR" color reaction

Milestone 3: Recovery Sequence

Sensing ALL colors during recovery:

- Problem: Recovery sequence only checked for Follow_colors.
- Caused it to ignore boundary colors
- Solution: Moved color reaction code in one function to allow detection of all colors in one sweep.
- Significantly improved recovery, allowed reaction to all colors.


```
bool handleColorReaction(String color, float r, float g, float b, float lux) {  
    // ----- TURN MARKERS -----  
    if (color == LEFT_TURN_MARKER) { ...  
    }  
    if (color == RIGHT_TURN_MARKER) { ...  
    }  
    // ----- FLOOR FALL PROTECTION -----  
    if (color == "FLOOR") { ...  
    }  
    // ----- FOLLOW-COLORS -----  
    bool isFollowColor = false;  
    for (int i = 0; i < NUM_FOLLOW_COLORS; i++) ...  
    if (isFollowColor) { ...  
    }  
    // ----- BOUNDARIES -----  
    if (color == LEFT_BOUNDARY_COLOR) { ...  
    }  
    if (color == RIGHT_BOUNDARY_COLOR) { ...  
    }  
    return false;    // No reaction → normal recovery sequence should continue  
}
```

Color handler function

Milestone 3: Recovery Sequence

New sequence:

- Forward -> Left -> Right -> Right -> Left
- Inspired from the simple pendulum motion.
- Rover ended the sequence facing front.
- Recovery sequence almost always triggered near the boundary of the tapes.
- Enabled immediate recovery from “Unknown” reading on color sensor.



New Recovery Cycle